
3-2. Using the air conditioning system and defogger Front air conditioning system (without rear air conditioning system)

Airflow and outlets are automatically adjusted according to the temperature setting. Press to display the air conditioning operation screen. Air conditioning operation screen display button Airflow display Fan speed display Air conditionina on/off switch temperature control Passenger's side Dual operation button temperature control Automatic mode Outside air or recirculated air mode Driver's side temperature Passenger's side display Off. temperature display Windshield defogger Micro dust and pollen filter This illustration is for a vehicle equipped with the navigation system.

Using the speech command system (if equipped)



Pull to operate the speech command system. (→ "Navigation System Owner's Manual")

Using the automatic mode





The air conditioning system will begin to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting.

STEP 2 Press to switch to automatic air intake mode.

The air conditioning system automatically switches between outside air and recirculated air modes.

STEP 3 Press ∧ on



to increase the temperature and \lor to decrease

the temperature.

The temperature for the driver and passenger seats can be set separately.

Adjusting the settings

n Adjusting the temperature setting

Press ∧ on



to increase the temperature and \vee to decrease the

temperature.

The air conditioning system switches between dual and simultaneous modes each time [is pressed.

Dual mode (the indicator on is on.): The temperature for the left-hand seat and right-hand seat can be adjusted separately. Operating the passenger's side temperature control will enter dual mode.

Simultaneous mode (the indicator on $\overline{\mbox{\tiny box}}$ is off.): Only




side) can used to adjust the temperature for all seats.

${\bf n}$ Adjusting the fan speed

Touch any switch of $(decrease \leftrightarrow increase)$ on the operation screen.


Press Foff to turn the fan off.

n Changing the air outlets




Touch any mode on the operation screen.


Air flows as shown below according to the mode selected.




Upper body



Upper body and feet



Feet



Feet and front windshield


n Switching between outside air and recirculated air modes

Press .

The mode switches between (recycles air inside the vehicle), "AUTO" and (introduces air from outside the vehicle) modes each time the button is pressed.

When the air intake control system is switched to automatic mode, it operates automatically.

Defogging the windshield



Press 📆.

The air conditioning system control operates automatically.

Micro dust and pollen filter



Press 👼 .

Outside air mode switches to (recirculated air) mode. Pollen is removed from the air and the air flows to the upper part of the body.


Usually the system will turn off automatically after approximately 3 minutes.

To stop the operation, press again.



Adjusting the sensitivity of the air intake control in automatic mode


Press until the "Smog Sensor" screen appears while the vehicle is stopped.




Touch any switch of (lower sensitivity ↔ higher sensitivity) on the operation screen.


Adjusting the position and opening and closing the air outlets

► Front center outlets



- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.





- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.

► Rear center outlets



- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.

Rear side outlets



- Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

n Using the automatic mode

Fan speed is adjusted automatically in accordance with the temperature setting and ambient conditions. As a result, the following may occur:

- 1 The system may switch automatically to recirculated air mode when the coolest temperature setting is selected in summer.
- I Immediately after is pressed, the fan may stop for a while until warm or cool air is ready to flow.
- 1 Cool air may flow to the area around the upper body when the heater is on.

$n\ \ \mbox{Using the system in recirculated air mode}$

The windows will fog up more easily if the recirculated air mode is used for an extended period.

n Window defogger feature

Recirculated air mode may automatically switch to (outside air) mode in situations where the windows need to be defogged.

n When the hybrid battery cooling system operates

If the hybrid battery cooling system operates when the air conditioning is off, a message will be shown on the multi-information display and the air conditioning will automatically turn on. $(\rightarrow P. 184)$

n Automatic mode for air intake control

In automatic mode, the system detects exhaust gas and other pollutants and automatically switches between outside air and recirculated air modes.

When the air conditioning is off, and the fan is operating, turning the "AUTO" mode on will activate the air conditioning system.

n Micro dust and pollen filter

- 1 In order to prevent the windows from fogging up when the outside air is cold, the following may occur:
 - Outside air mode does not switch to
 - The air conditioning system operates automatically.
 - The operation cancels after 1 minute.

A CAUTION

n To prevent the windshield from fogging up

Do not use during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.




NOTICE


n To prevent the 12-volt battery from being discharged

Do not leave the air conditioning system on longer than necessary when the hybrid system is off.

3-2. Using the air conditioning system and defogger Front air conditioning system (with rear air conditioning system)



Using the speech command system (if equipped)



Pull to operate the speech command system. (→ "Navigation System Owner's Manual")

Using the automatic mode





The air conditioning system will begin to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting.



STEP 2 Press to switch to automatic air intake mode.

The air conditioning system automatically switches between outside air and recirculated air modes.

STEP 3 Press ∧ on



to increase the temperature and \vee to decrease

the temperature.

Air outlets and fan speed for the right-hand and left-hand seats may be set separately depending on the temperature setting.

Adjusting the settings

n Adjusting the temperature setting




to increase the temperature and \vee to decrease the

temperature.

The air conditioning system switches between individual and simultaneous modes each time will is pressed.

Individual mode (the indicator on is on.): The temperature for the driver's, front passenger's and rear seats (→P. 282) can be adjusted separately. Operating the passenger's side temperature control will enter individual mode.

Simultaneous mode (the indicator on is off.): Only





side) can be used to adjust the temperature for all seats.

n Adjusting the fan speed

Touch any switch of (decrease ↔ increase) on the operation screen.

Press *off to turn the fan off.

n Changing the air outlets




Touch any mode on the operation screen.


- L: Left-hand front seat
- R: Right-hand front seat

Different air outlets for the lefthand and right-hand front seats can be chosen.


Air flows as shown below according to the mode selected.




Upper body



Upper body and feet



Feet



Feet and front windshield

n Switching between outside air and recirculated air modes

Press .

The mode switches between (recycles air inside the vehicle), "AUTO" and (introduces air from outside the vehicle) modes each time the button is pressed.

When the air intake control system is switched to automatic mode, it operates automatically.

Turning the air purifier off

Touch on the operation screen.

The air purifier will turn off when the indicator on the switch goes off. Air will not flow from the roof vents.

To turn the air purifier on, touch again.

Changing the rear seat settings

n Adjusting the temperature setting






Touch (increase) or (decrease) on the operation screen. Operating the switch will enter individual mode.

- 1 L: Left-hand rear seat
- R: Right-hand rear seat

The air conditioning system switches between individual and simultaneous modes each time is pressed.

 $n\,$ Adjusting the fan speed (air purifier and cool air from the roof vents)




Touch any switch of the operation screen. (decrease ↔ increase) on the operation screen.

According to the air outlets currently selected, the fan speed of either the cool air from the roof vents or air purifier will be adjusted. $(\rightarrow P. 284)$

Press roturn the fan off.

Defogging the windshield



Press .

The air conditioning system control operates automatically.

Micro dust and pollen filter



Press 💹

Outside air mode switches to (recirculated air) mode. Pollen is removed from the air and the air flows to the upper part of the body.


Usually the system will turn off automatically after approximately 3 minutes.

To stop the operation, press again.



Adjusting the sensitivity of the air intake control in automatic mode


Press until the "Smog Sensor" screen appears while the vehicle is stopped.



Touch any switch of (lower sensitivity ↔ higher sensitivity) on the operation screen.


Adjusting the position and opening and closing the air outlets

► Front center outlets



- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.

▶ Front side outlets



Air outlets of the rear seat. $(\rightarrow P. 285)$

- Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

n Using the automatic mode

Fan speed is adjusted automatically in accordance with the temperature setting and ambient conditions. As a result, the following may occur:

- 1 The system may switch automatically to recirculated air mode when the coolest temperature setting is selected in summer.
- I Immediately after is pressed, the fan may stop for a while until warm or cool air is ready to flow.
- 1 Cool air may flow to the area around the upper body when the heater is on.

n Using the system in recirculated air mode

The windows will fog up more easily if the recirculated air mode is used for an extended period.

n Window defogger feature

Recirculated air mode may automatically switch to (outside air) mode in situations where the windows need to be defogged.

n When the hybrid battery cooling system operates

If the hybrid battery cooling system operates when the air conditioning is off, a message will be shown on the multi-information display and the air conditioning will automatically turn on. $(\rightarrow P. 184)$

n Automatic mode for air intake control

In automatic mode, the system detects exhaust gas and other pollutants and automatically switches between outside air and recirculated air modes.

When the air conditioning is off, and the fan is operating, turning the "AUTO" mode on will activate the air conditioning system.

n Micro dust and pollen filter

- 1 In order to prevent the window from fogging up when the outside air is cold, the following may occur:
 - Outside air mode does not switch to <
 - · The air conditioning system operates automatically.
 - The operation cancels after 1 minute.
- 1 In rainy weather, the windows may fog up. Press 🔝 .

n Air purifier

The air purifier will turn on when turning the rear air conditioning system on.

A CAUTION

n To prevent the windshield from fogging up


Do not use 🔝 during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.




n To prevent the 12-volt battery from being discharged

Do not leave the air conditioning system on longer than necessary when the hybrid system is off.

3-2. Using the air conditioning system and defogger Rear air conditioning system (if equipped)





Using the automatic mode



The air conditioning system and air purifier will operate, and air outlets and fan speed will be set automatically.

"AUTO" will be displayed on the control panel.



to increase the temperature and \lor to decrease

the temperature.

Air outlets and fan speed for the right-hand and left-hand seats may be set separately depending on the temperature setting.

Adjusting the settings

n Adjusting the temperature setting



 $^{
m TEMP}$ to increase the temperature and ee to decrease the

temperature.


Air outlets and fan speed for the right-hand and left-hand seats may be set separately depending on the temperature setting.

n Changing the air outlets


Press



The air outlets change as follows each time the $\ensuremath{\wp}$ is pressed.




Air flows as shown below according to the mode selected.




Upper body

When the indicator on (on the front operation screen) is on




Upper body

When the indicator on (on the front operation screen) is off



Upper body and feet



Feet

n Adjusting the air volume


The volume of cool air or air from the air purifier can be adjusted according to the mode selected.

Press \land (increase) or \lor (decrease) on \lor \lor



Zi Yasaanaa

Cool air flows from roof vents.



Air purifier operation (air flows from the rear package tray.)

Press to turn the fan off.

Adjusting the position and opening and closing the air outlets

► Rear center outlets




- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.

► Rear side outlets



- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.

► Roof side outlets



Direct air flow to the left or right, up or down.

n Button lock function

► 5-seat models



on the rear armrest can be locked. Press until you hear a beep to lock the buttons.

Pressing again until you hear a beep will release the lock.

To prevent inadvertent operation, the buttons

The indicator appears on the display when the buttons are locked.

► 4-seat models



n Rear control panel illumination off function

► 5-seat models



Control panel illumination on the rear armrest can be turned off. Press until you hear a beep to turn the illumination off. Pressing again until you hear a beep will turn the illumination on.

4-seat models



n Replacing the rear air conditioning filter

Replacing the air filter when using rear air conditioning or air purifier reduces air flow or deodorizing performance. $(\rightarrow P. 551)$



$n\,$ To prevent the 12-volt battery from being discharged

Do not leave the air conditioning system on longer than necessary when the hybrid system is off.

3-2. Using the air conditioning system and defogger Rear window and outside rear view mirror defoggers

These features are used to defog the rear window, and to remove raindrops, dew and frost from the outside rear view mirrors.



On/off

Press the button to turn on the rear window and outside rear view mirror defoggers. The defoggers will automatically turn off after approximately 15 minutes. Pressing the button again also turns the defoggers off.

A CAUTION

n When the outside rear view mirror defoggers are on

Do not touch the outside surface of the rear view mirrors, as they can become very hot and burn you.


3-2. Using the air conditioning system and defogger Windshield wiper de-icer (if equipped)

This feature is used to prevent ice from building up on the windshield and wiper blades.

► Vehicles without navigation system









On/off

Touch the switch to turn on the windshield wiper de-icer. The windshield wiper de-icer will automatically turn off after approximately 15 minutes. Touching the switch again also turns the de-icer off.

► Vehicles with navigation system







On/off

Touch the switch to turn on the windshield wiper de-icer. The windshield wiper de-icer will automatically turn off after approximately 15 minutes. Touching the switch again also turns the de-icer off.



A CAUTION

n When the windshield wiper de-icer is on

Do not touch the glass at the lower part of the windshield or to the side of the front pillars as the surfaces can become very hot and burn you.